

# **Split Systems**

FaultsLGMV program for service

#### 7. Self Diagnosis

Error Code	Error Indicator	Cause of Error	Dis Indeer	play Outdoor	indoor Operation
1	1 time 1 time 1 time 1 time 1 time + + + + + + + + + + + + + + + + + + +	<ul> <li>Indoor Temp. sensor error</li> <li>Sensor open or short</li> </ul>	0		ON
Ŋ	21mas	<ul> <li>Outdoor Temp. sensor error</li> <li>Sensor open or short</li> </ul>	0	0	ON
4	41mes 41mes 3sec 3sec	<ul> <li>Heat Sink sensor error</li> <li>Sensor open or short</li> <li>Heat Sink temp is over 95.</li> </ul>	0	Q	ON
5	Stimes Saec	<ul> <li>Communication error</li> </ul>	0	0	OFF
6	Stimes Stimes	• DC Peak error	0	0	SHUT DOWN
7	7times 	Over current error (CT2)	0	0	SHUT DOWN
8	8times 8times Sae⊂	<ul> <li>Indoor fan lock error (BLDC fan model only)</li> </ul>	0		OFF
9	0times ↓ 3 sec	Outdoor tan lock error (BLDC fan model only)	0	0	OFF
10	i0 times at 0 times. <del>     →</del> → 3 sec	<ul> <li>D-Pipe TH. is short or open.</li> </ul>	0	0	Ň
12	ttimo 21mes ttimo 21mes S sec 3 sec	EEPROM Error     EEPROM Check sum Error		0	ON
18	Stimes Stimes Stimes	PSC Error     PSC Fault Error		0	ON
14	ttime 4 time 4 time 4 time 4 times	<ul> <li>Comp Phase Current Error (180 Driver Comp Control Model Only)</li> </ul>		0	ON

# **R** Series air cons

Indoor Error	Description	LED 1	LED 2
1	Indoor sensor (AIR) Open/Short	1 TIMES	
2	Indoor sensor (entry pipe) Open/Short	2 TIMES	
5	Communication error	5 TIMES	•
6	Indoor sensor (exit pipe) Open/Short	6 TIMES	
9	EEPROM error (Indoor)	9 TIMES	
10	Indoor fan lock (operational failure)		1 TIMES
12	Indoor sensor (Middle Pipe) Open/Short	2 TIMES	1 TIMES



Eman		Error Indication			
Code	Description	Indoor Unit		Outdoor Unit	
ooue		LED1	LED2	LED1	LED2
21	DC Peak (IPM Fault)	2 Times	1 Time	2 Times	1 Time
22	CT 2(Max CT)	2 Times	2 Times	2 Times	2 Times
23	DC Link Low Volt	2 Times	3 Times	2 Times	3 Times
25	Low wire volt/ high wire volt	2 Times	5 Times	2 Times	5 Times
26	DC Comp Position Error	2 Times	6 Times	2 Times	6 Times
27	PSC Fault Error	2 Times	7 Times	2 Times	7 Times
28	DC Link High Volt	2 Times	8 Tiems	2 Times	8 Tiems
29	Inverter Compressor over-current	2 Times	9 Times	2 Times	9 Times
31	CT error (low current)	3 Times	1 Time	3 Times	1 Time
32	D-Pipe High (INV)	3 Times	2 Times	3 Times	2 Times
40	CT Sensor (Open / Short)	4 Times	-	4 Times	-
41	INV. D-Pipe Th Error (Open / Short)	4 Times	1 Time	4 Times	1 Time
44	Outdoor Air Th Error (Open / Short)	4 Times	4 Times	4 Times	4 Times
45	Cond. Middle Pipe Error (Open / Short)	4 Times	5 Times	4 Times	5 Times
48	Cond. Out Pipe Error (Open / Short)	4 Times	8 Tiems	4 Times	8 Tiems
53	Communication Failure(Outdoor Unit ↔ Indoor Unit)	5 Times	3 Times	5 Times	3 Times
60	EEPROM Check Sum Error	6 Times	-	6 Times	-
61	Cond. Pipe High	6 Times	1 Time	6 Times	1 Time
62	Heatsink High	6 Times	2 Times	6 Times	2 Times
63	Cond. Pipe Low	6 Times	3 Times	6 Times	3 Times
65	Heatsink Th Error (Open/Short)	6 Times	5 Times	6 Times	5 Times



## **Faults R series**

Error Code	Description	Cause	Check
01	Indoor temp sensor	Short open/ Short	Check connection and resistance
02	Indoor pipe entry temp sensor	Short open/ Short	Check connection and resistance
06	Indoor pipe exit temp sensor	Short open/ Short	Check connection and resistance
12	Indoor pipe mid temp sensor	Short open/ Short	Check connection and resistance

1. Check that the connection is secure on PCB

2. After disconnecting from PCB check resistance



# R series cont...

Symbol	Colour connector	Title	Resistance	Remark
TH1	White (CN- TH1)	Indoor pipe	10kΩ	25∙C Basis
TH2	RED (CN-TH2)	Mid pipe	5kΩ	25•C Basis
TH3	White (CN-TH3)	Exit pipe	5 kΩ	25•C Basis

If the measurement indicates infinite (∞) or 0 Ω replace sensor
 If the measurement is normal then check indoor board



# **CH05 ERROR R Series**

Inspection Number	Description of Inspection	Cause of Error	Check Point
CH05	Poor Communication (Indoor <-> Outdoor unit)	The communication between indoor <-> outdoor unit is stopped for more than 3 minutes.	<ul> <li>AC 220V power input(indoor, outdoor unit)</li> <li>Disconnection of the transmission connection</li> <li>Poor connection of connecting wires</li> <li>Communication line short in GND</li> <li>No power to outdoor unit PCB(burned) / faulty communication circuit</li> <li>faulty outdoor unit PCB communication circuit</li> <li>GND 1, 2 not connected to the main power GND</li> </ul>

- 1. Check input power AC 220V (indoor, outdoor unit)
- Check proper connection of the communication line => check the status of the connection wire fault and connector connections.
- 3. Check the resistance between the communication line and GND (normal : 2kΩ or more)
- 4. Check if the communication connections are properly connected.
- 5. Check indoor unit GND, outdoor unit GND, and main GND connections.
- 6. If the length of the communication line exceeds 50M, separate the communication lines.
- 7. Check for the products or power lines near the communication line that may cause noise.

# CH06 ERROR R SERIES

Error code	Description of error	Cause of error	Check point
CH06	Indoor pipe exist temp sensor	Blocked filters Sensor short/open	Check filters Check sensor connection status and check sensor Resistance

## Make sure the indoor filters are clean

## CH09 & Ch10 fault R Series

Error code	Description of error	Cause of error	Check point
CH09	CN-Option PCB	Poor connection	Check connection of option PCB



Error code	Description of error	Cause of error	Check point
CH10	Indoor fan locking	If the indoor fan motor does not operate after 1 minute on start up	<ol> <li>Locking of fan</li> <li>Poor connection</li> <li>Faulty motor</li> <li>Faulty indoor PCB</li> </ol>

## CH21 fault R Series

#### 1) CH21: DC Peak Error

Inspection Number	Error Detection	Cause of Error	Check Point
CH21	High current into the compressor	<ul> <li>Compressor blocked</li> <li>Disconnection/short- circuit inside compressor</li> <li>Over load operation (Outdoor fan constraint, screened, blocked)</li> <li>Burned parts inside PCB</li> </ul>	<ul> <li>Check compressor constraint</li> <li>Check compressor wire open/short</li> <li>Check compressor insulation damage</li> <li>Check outdoor fan constraint / screened / flow structure</li> <li>Check if IPM burned</li> </ul>

Before checking PCB or each outdoor electric parts, wait for 3 minutes after the power is off.
 When measuring at standby state of power supply, after checking the measurement mode of the meter, be careful of the short-circuits with other parts.



Table 1
---------

Resistance between the			
lines of each terminal			
0.5 ~ 1Ω			
0.5 ~ 1Ω			
0.5 ~ 1Ω			

Table 1

Resistance of termina insulations			
U - chassis	1MΩ ↑		
V - chassis	1MΩ ↑		
W - chassis	1MΩ ↑		

Blocked Filters can cause this error code Please check make sure filters are clean

# CH22 & CH 23 fault R Series

Error code	Description of error	Cause of error	Check point
CH22	AC input current is higher than the limit	Input voltage error(low Voltage) Over load operation Burnt parts	<ol> <li>Check input voltage</li> <li>Check outdoor fan</li> <li>Check PCB</li> </ol>

Error code	Description of error	Cause of error	Check point
CH23	DC link voltage is lower than the limit (under DC 140VMS)	Input voltage error	<ol> <li>Check input voltage</li> <li>Check PCB link voltage sensor parts</li> </ol>

# CH 26, Ch 27 fault R series

Error code	Description of error	Cause of error	Check point
CH27	Over current on AC> DC converter circuit	<ol> <li>Overload operation</li> <li>Wrong application of reactor Spec.</li> <li>Burned PCB internal parts</li> </ol>	<ol> <li>Check outdoor fan constraint / screened</li> <li>Check Reactor Spec</li> <li>Check for PCB internal part burn</li> </ol>

Error code	Description of error	Cause of error	Check point
CH26	Over- current at the initial operation of the compressor / location sensing signal for compressor operation is not input	<ol> <li>Compressor Locking</li> <li>Overload operation, outdoor fan blocked</li> <li>Burnt parts inside PCB</li> <li>Burnt PCB phase</li> </ol>	<ol> <li>Check compressor locking</li> <li>Compressor wire open/short</li> <li>Check compressor insulation damage</li> <li>Check outdoor fan constraint</li> </ol>

# CH 29 & Ch32 fault R series

Error code	Description of error	Cause of error	Check point
CH29	Compressor input phase current is high	<ol> <li>Compressor blocked</li> <li>Overload operation fan blocked</li> <li>Burned PCB phase current sensor part</li> </ol>	<ol> <li>Check compressor locking</li> <li>Check outdoor fan constraint</li> <li>Check for PCB phase sensor part</li> </ol>

Error code	Description of error	Cause of error	Check point
CH32	High temp in discharge pipe of the inverter compressor	Overload operation (check fan blocked) Refrigerant leak Poor inv comp discharge sensor LEV connector displaced poor LEV assembly	Check outdoor fan Check refrigerant Check sensor

## CH40 etc faults R series

Error code	Descripti	on of error		Cause of error	Check point
CH40	AC input current comp phase change voltage error		1. PCB sensing circuit part burned	Check power input connector comp output current sensing circuit	
Error code		Description of error		Cause of error	Check point
CH41		Inv D-pipe sensor Open/ short	Sen	sor displaced	Check status of sensor assembly
CH44		Outdoor inlet sensor Open/ short	Sen	isor burned	Check sensor is burned
CH45		Cond pipe sensor Open/short			
CH 65		b/diode Heat sink			

Open/ short

Sensor Resistance Value 25 C basis Inv D pipe sensor 200K Outdoor inlet sensor 10K Cond pipe sensor 5K B/Diode Heat Sink Sensor 10K

# CH 53 & CH 60 faults R series

Error code	Description of error	Cause of error	Check point
CH53	If the data transmitted by the indoor unit is not received for 3mins cont	<ol> <li>No power to indoor unit.</li> <li>Indoor/ outdoor unit power connection</li> <li>Communication error caused by external noise</li> <li>Indoor/ outdoor communication parts are burnt</li> </ol>	<ol> <li>Check outdoor unit power status</li> <li>Check indoor/outdoor unit</li> <li>Check outdoor indoor communication</li> </ol>
and the second	NUMBER OF STREET	States and Street of Stree	
Error code	Description of error	Cause of error	Check point

CH60	Incorrect Check sum of outdoor PCB EEPROM	Outdoor unit PCB EEPROM misapplied Outdoor unit PCB EEPROM poor assembly	EEPROM assembly

# CH61 & CH 62

Error Code	Error Detection	Cause of Error	Check Point
CH61 On cooling	Condenser pipe sensor high	Abnormality of pipe sensor	Check temp sensor In case resistance value is OK exchange PCB
CH61 On heating	Middle pipe sensor indoor unit over temp	Sensor resistance high	Check indoor mid pipe sensor resistance

Error	Error detection	Cause	Check
CH62	High temp in outdoor PCB Heat Sink	Overload operation Poor PCB heat sink Poor PCB temp sensing parts	<ol> <li>Check outdoor fan</li> <li>Check PCB heat sink connection</li> <li>Check PCB temp sensing parts</li> </ol>

# Ch 67 Fault R Series

Error Code	Description	Cause	Check
CH67	The outdoor unit fan does not come on	<ol> <li>Outdoor fan lock</li> <li>PCB connector displaced</li> <li>outdoor PCB is faulty</li> </ol>	<ol> <li>Check status outdoor fan</li> <li>Check of PCB fan connector assembly</li> <li>Check fan motor wire</li> <li>Check fan motor wire</li> </ol>

#### **Control Parts** / 2)Self-Diagnosis Function older air con includes S series

#### Self-diagnosis Function

This function shows the state of air conditioner and indicates the cause of trouble when trouble occurs.



Error Code	Description	Display of Operating LED	Operating State
1	Indoor TH. is short or open	Blinks once	Keep operating (On)
2	Outdoor TH. is short or open	Blinks twice	Keep operating (On)
4	Heat-sink Temp. is over 95°C / Heat-sink TH. is short or open	Blinks 4 times	Compressor restarts when Heat-sink Temp. is below 85°C
5	Communication error (serial communication)	Blinks 5 times	Off (enable to restart by remote control)
6	DC peak error	Blinks 6 times	Off (unable to restart by remote control)
7	Running current is overloaded (CT2)	Blinks 7 times	Off (unable to restart by Remote control)
8	Indoor fan is locked (DC fan only)	Blinks 8 times	Off
9	Outdoor fan is locked (DC fan only)	Blinks 9 times	Off
10	D_Pipe TH. is short or open	Blinks 10 times	Compressor off

#### \* Outdoor Error Indicator (LED01M on outdoor pcb assembly)

Error Code	Description	Display of LED01M	Operating State
2	Outdoor TH. is short or open	Blinks twice	Keep operating (On)
4	Heat-sink Temp. is over 95°C / Heat-sink TH. is short or open	Blinks 4 times	Compressor restarts when Heat-sink Temp. is below 85°C
5	Communication error (serial communication)	Blinks 5 times	Off (enable to restart by remote control)
6	DC peak error	Blinks 6 times	Off (unable to restart by remote control)
7	Running current is overloaded (CT2)	Blinks 7 times	Off (unable to restart by Remote control)
9	Outdoor fan is locked (DC fan only)	Blinks 9 times	Off
10	D_Pipe TH. is short or open	Blinks 10 times	Compressor off



Error code	Description		Cause of error		
2	Outdoor TH. is short or open	<ul> <li>Outdoor TH. (sensor) is short or open</li> <li>Outdoor TH. (sensor) is not connected to the outdoor pcb assembly</li> <li>Damage or defect on the sensing circuit of outdoor pcb assembly. (pattern from CN-TH1 to micom port 5, 6. R03H : 1K, R04H : 12.1K, R05H : 1K, R06H : 6.2K, C02H : 10uF, C03H : 10uF)</li> </ul>			
Check	flowYES	3	YES		
Outde	oor TH. is connected to outdoor pcb assembly ?	► Outdoor TH. is right ?	Sensing circuit of outdoor pcb is right ?		
	No	No	No		
Connect t	to CN-TH1 in outdoor pcb assembly	Check outdoor TH. - Measure resistance of TH. (air : about 10kΩ at 25°C, pipe : about 5kΩ at 25°C)	<ul> <li>Check soldering state of R03H, R04H, R05H R06H, C02H, C03H</li> <li>Check spec of R03H, R04H, R05H, R06H, C02H, C03H</li> <li>(R03H : 1K, R04H : 12.1K, R05H : 1K, R06H : 6.2K, C02H : 10uF, C03H : 10uF)</li> </ul>		



Error code	D	escription		Cause of error	
5	Comm	nunication error	<ul> <li>Wiring error : Wrong or miss</li> <li>AC Power Connector is not</li> <li>Defect of communication co (D01K, R01K~R04K, IC01K</li> <li>Defect of communication co (D01K~D03K, ZD01K~ZD03)</li> <li>Defect of outdoor pcb assent</li> <li>No ground connection in air</li> </ul>	sing wiring between indoor ar connected to the T/Block from mponents in indoor pcb asse , IC02K, ZD01K, Q01K, C01 mponents in outdoor pcb ass 3K, R01K~R10K, C01K~C04 nbly. conditioner unit (affected by	nd outdoor unitcable m pcb (Indoor unit) embly. K) sembly. K) noise in power source)
Check	flow		۲YES۲	'ESY	ES
Wiring cor is rigl	nnection	Is the voltage of T/Block ①, ② in outdoor about AC 220/240V ?	■ Is the voltage of GND & DC5V in outdoor pcb about DC 5V ?	Communication circuit of indoor & outdoor pcb Is right ?	(power outlet or outdoor Chassis)
No 🚽		No	No	No	No _
Indoor C 1(BR) 2(BL) 3(GN/YL) 4(RD)	Dutdoor 1(BR) 2(BL) 3(GN/YL) 4(RD)	Check power connector Is not connected to the T/Block in indoor unit.	Check FUSE, NF01/02J, PTC, Power Module, PSC Module in outdoor pcb assembly (If any one has defect, replace pcb assembly)	Check IC01K, IC02K, D01K~D03K, ZD01K~ ZD03K, R01K~R10K, C01K~C04K	Install ground connection from outdoor unit. (In case power outlet has no earth port)
					Earth port

Error code	Description		Cause of error				
6	DC peak error	<ul> <li>Supplied power is not normal</li> <li>Connector (CN-U,V,W) is discort</li> <li>Compressor is damaged (coil sl</li> <li>Refrigerant pressure is too high</li> <li>Defect in outdoor pcb assembly</li> </ul>	<ul> <li>Supplied power is not normal</li> <li>Connector (CN-U,V,W) is disconnected or inserted to wrong position</li> <li>Compressor is damaged (coil short) ⇒ Replace compressor</li> <li>Refrigerant pressure is too high</li> <li>Defect in outdoor pcb assembly ⇒ Replace pcb assembly</li> </ul>				
Check	flow						
Supplied v Outdoor pc AC 220/ No Check pow	ver source	V,W) essor o in Check	YES Is the compressor right ? No Check resistance YES Refrigerant pressure is right ? No Check refrigerant				
	Check CN–U,V,W con (U : RD, V : BL, W :	<ul> <li>(1) Short of SPM3 pins</li> <li>(2) Assembling state of R17Z(27mΩ)</li> <li>(3) Direction of D01Z~D03Z, C08Z,10Z,12Z,16Z</li> <li>(4) Assembling state of R01P ~ R21P &amp; IC01P</li> <li>(5) Assembling state of screw between SPM3 &amp; Heatsink</li> <li>(6) DC 15V output of Power module.</li> </ul>	<ul> <li>④ Between U-V, V-W, U-W port.</li> <li>→ Short / Open circuit (Comp.motor coil error)</li> <li>→ normal : 1 ~2 Ω</li> <li>② Between U,V,W and Body</li> <li>→ normal : over1MΩ</li> </ul>				

Error code	Description	Cause of error
7	Over current error (CT2)	<ul> <li>Supplied power is not normal</li> <li>Indoor / outdoor fan is locked</li> <li>Refrigerant pressure is too high</li> <li>Defect in current sensing circuit in outdoor pcb assembly</li> </ul>



Error code	Descri	ption	_	Cause of erro	or
8	Indoor fan (for DC fa	is locked n model)	<ul> <li>Indoor fan is I</li> <li>Fan connecto</li> <li>Defective in E</li> </ul>	ocked or separated. or is not connected to indoor pcb DC-fan driving circuit	assembly
Check	flow				
		Contraction of the local division of the loc	YES		
Indoor fai	n is rotating ? (1)	Outdoor fan is r	rotating ? (2)	DC-fan driving	circuit is right ?
N	o _	No		No	
Check ind - remove indoor u - fan asse	oor unit obstacles in unit embled correctly.	Check solderin CN-Motor1 & State of DC Fa	ng state of assembling In connector	- Check DC Fan Driving circuit (S R01F~R09F, C01F~C03F, IC0	Coldering state & Direction) 1F~IC03F, Q01F~Q02F, ZD01F

Error code	Descri	ption	Cause of error
9	Outdoor far (for DC fai	n is locked n model)	<ul> <li>Outdoor fan is locked by an obstacle (ex: branch of tree, baretc)</li> <li>excessive head wind</li> <li>Fan connector is not connected to outdoor pcb assembly</li> <li>Defective in DC-fan driving circuit</li> </ul>
Check	flow		YES
Outdoor f	an is rotating ? (1)	Outdoor fan is	s rotating ? (2) DC-fan driving circuit is right ?
N	lo 🚽	No	No
Check ou - remove in outdo - if heavy blows tr make p	tdoor unit obstacles oor unit head wind o outdoor fan, protection	Check connected to assembly (d	ector is not outdoor pcb (CN-FAN2) - Check DC Fan driving circuit (Soldering state & Direction) R01F~R05F, C01F~C03F, Q01F~Q04F, ZD01F

Error code	Description	Ca	ause of error			
10	D_PIPE TH. is short or open	<ul> <li>D_PIPE TH. (sensor) is short or open</li> <li>D_PIPE TH. (sensor) is not connected to the outdoor pcb assembly</li> <li>Damage or defect on the sensing circuit of outdoor pcb assembly.</li> <li>(pattern from CN-D_PIPE to micom port 4. R07H : 1K, R08H : 18K, C04H :10uF)</li> </ul>				
Checl	<mark>د flow</mark> ۲	/ESYF9				
D_P	PIPE TH. is connected to outdoor pcb assembly ?	→ D_PIPE TH. is right ?	Sensing circuit of outdoor pcb is right ?			
	No 🖌	No	No			
Connect	to CN-D_PIPE in outdoor pcb assembly	Check D_PIPE TH. - Measure resistance of TH. (about 200kΩ at 25℃.)	<ul> <li>Check soldering state of R07H, R08H, C04H</li> <li>Check spec of R07H, R08H, C04H (R07H : 1K, R08H : 18K, C04H : 10uF)</li> </ul>			
	PRILE BKBD					

### 4-2.Control Parts / 4)Others

#### **Communication Block Diagram**





### Service LGMV program

- This program can assist you in the diagnostics of inverters. ( **LG recommend this**)
- You can monitor and save to your computer the running temperatures, operating frequency, fan status, of inverter air conditioning to save time and eliminate false diagnostics.
- The LGMV program can be purchased as a spare part by our spare parts department- part numbers- 5001A90032E & 5001A20200F





#### Information gathered On indoor unit and outdoor

			5		S	ystem Grap display	h
a Current Data Reg Mode Arrent Har Internet	THE THE REAL				The P	Full Open: Full Chose Text Transit Full Chose	-
Value Camp City E Value Outbury Unit Into 4.0 Into 4.8 T B - 121 5 Camp	11,0 ve	Profession Profession	en reave a e reave and late	SAN 2004		Outdoor information	
a Reader (4 2年) 4 201 4 202 4 202 4 202 5 20 5 20	11-82 11-82 12-85 12-86	The restore 2.5 If	12878+ × × × × × × × × × × × × × × × × × × ×	10 10 10 10 10 10 10 10 10 10 10 10 10 1	Indoor in	formation	
Aller TH of the second	CATE	0428.0 0.0 10-7948.0	BRANCON MO	NOTARON THEORY			
	agh COL	INCOL NUMERON AND AND AND AND AND AND AND AND AND AN	A STAN MOUNTS	ALC INC	NATE OF CONTRACT OF CONTRACT.		

Operating status