

# *Service manual*

*Room airconditioner*

*Split Wall-Mounted Type*

*Applied to:*

MSC-18HRIN1; MSH-18HRIN1(AAC-18ISCH)  
MSE-09HRIN2; MSE-12HRIN2  
MSG-07CRIN2; MSG-09HRIN2  
MSG-12HRIN2;  
MSG-09HRI ;MSG-12HRI  
MSG-21HRI ; MSG-24HRI

---

**NOTE:**

Before servicing the unit, please read this at first.  
Always contact with your service center if meet problem.

# Content

<b>1.</b>	<b>Precaution .....</b>	<b>1</b>
1.1	Safety Precaution .....	1
1.2	Warning .....	1
<b>2.</b>	<b>Function .....</b>	<b>3</b>
<b>3.</b>	<b>Dimension .....</b>	<b>5</b>
3.1	Indoor unit (Alfa) .....	5
3.2	Outdoor unit (Alfa) .....	5
3.3	Indoor unit (Corona) .....	6
3.4	Outdoor unit (Corona) .....	6
3.5	Indoor unit(Inverter Eco) .....	7
3.6	Outdoor unit(Inverter Eco) .....	7
3.7	Indoor unit(Inverter Star) .....	8
3.8	Outdoor unit(Inverter Star) .....	8
<b>4.</b>	<b>Specification .....</b>	<b>9</b>
<b>5.</b>	<b>Refrigerant cycle diagram .....</b>	<b>12</b>
<b>6.</b>	<b>Operation limits .....</b>	<b>13</b>
6.1	Cooling operation .....	13
6.2	Heating operation .....	13
<b>7.</b>	<b>Schematic diagram and Wiring diagram .....</b>	<b>14</b>
7.1.	Schematic diagram .....	14
7.2.	Wiring diagram .....	18
<b>8.</b>	<b>Installation details .....</b>	<b>23</b>
8.1	Wrench torque sheet for installation .....	23
8.2	Connecting the cables .....	23
8.3	Pipe length and the elevation .....	23
8.4	Air purging of the piping and indoor unit .....	24
8.5	Pumping down (Re-installation) .....	25
8.6	Re-air purging (Re-installation) .....	26
8.7	Balance refrigerant of the 2-way, 3-way valves .....	27
8.8	Evacuation .....	28
8.9	Gas charging .....	29
<b>9.</b>	<b>Pressure table .....</b>	<b>30</b>
9.1	MSH-18HRIN1 .....	30
9.2	MSC-18HRIN1 .....	30
<b>10.</b>	<b>Capacity table .....</b>	<b>31</b>
10.1	MSH-18HRIN1 .....	31
10.2	MSC-18HRIN1 .....	32
10.3	MSG-09HRI .....	33
10.4	MSG-12HRI .....	33
10.5	MSG-21HRI .....	34
10.6	MSG-24HRI .....	34

<b>11. Electronic function.....</b>	<b>35</b>
11.1. Display board.....	35
11.2. Protection .....	35
11.3. Fan-only mode.....	35
11.4. Cooling mode .....	35
11.5. Dehumidifying mode .....	36
11.6. Heating mode .....	36
11.7. Defrosting operation (Available for heating only). ....	38
11.8. Outdoor low temperature protection (optional) .....	38
11.9. Automatic operation mode .....	38
11.10. Manual switch .....	39
11.11. Timer Function.....	39
11.12. Sleep mode .....	39
11.13. Auto restart function.....	39
11.14. Turbo function .....	39
11.15. Plasma.....	39
<b>12. Model and Parameters.....</b>	<b>40</b>
<b>13. Troubleshooting .....</b>	<b>42</b>
13.1 Indoor Unit Error Display .....	42
13.2 Diagnostic chart.....	47
13.3 Resetting phenomenon often occurs during operation .....	48
13.4 Operation lamp flashes and Timer lamp off .....	48
13.5 Operation lamp flashes and Timer lamp on .....	48
13.6 Operation lamp off and Timer lamp flashes .....	49
13.7 Operation lamp on and Timer lamp flashes .....	49
13.8 Operation lamp flashes, Timer lamp flashes .....	49
<b>14 Characteristic of temperature sensor .....</b>	<b>50</b>



## 1. Precaution

### 1.1 Safety Precaution

- To prevent injury to the user or other people and property damage, the following instructions must be followed.
- Incorrect operation due to ignoring instruction will cause harm or damage.
- Before service unit, be sure to read this service manual at first.

### 1.2 Warning

#### ➤ Installation

- **Do not use a defective or underrated circuit breaker.**  
Use this appliance on a dedicated circuit.  
There is risk of fire or electric shock.
- **For electrical work, contact the dealer, seller, a qualified electrician, or an Authorized service center.**  
Do not disassemble or repair the product, there is risk of fire or electric shock.
- **Always ground the product.**  
There is risk of fire or electric shock.
- **Install the panel and the cover of control box securely.**  
There is risk of fire or electric shock.
- **Always install a dedicated circuit and breaker.**  
Improper wiring or installation may cause fire or electric shock.
- **Use the correctly rated breaker or fuse.**  
There is risk of fire or electric shock.
- **Do not modify or extend the power cable.**  
There is risk of fire or electric shock.
- **Do not install, remove, or reinstall the unit by yourself (customer).**  
There is risk of fire, electric shock, explosion, or injury.
- **Be caution when unpacking and installing the product.**  
Sharp edges could cause injury, be especially careful of the case edges and the fins on the condenser and evaporator.
- **For installation, always contact the dealer or an Authorized service center.**  
There is risk of fire, electric shock, explosion, or injury.
- **Do not install the product on a defective installation stand.**  
It may cause injury, accident, or damage to the product.
- **Be sure the installation area does not deteriorate with age.**  
If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury.
- **Do not let the air conditioner run for a long time when the humidity is very high and a door or a windows is left open.**  
Moisture may condense and wet or damage furniture.
- **Take care to ensure that power cable could not be pulled out or damaged during operation.**  
There is risk of fire or electric shock.
- **Do not place anything on the power cable.**  
There is risk of fire or electric shock.
- **Do not plug or unplug the power supply plug during operation.**  
There is risk of fire or electric shock.
- **Do not touch (operation) the product with wet hands.**  
There is risk of fire or electric shock.
- **Do not place a heater or other appliance near the power cable.**  
There is risk of fire and electric shock.
- **Do not allow water to run into electric parts.**  
It may cause fire, failure of the product, or electric shock.
- **Do not store or use flammable gas or combustible near the product.**  
There is risk of fire or failure of product.
- **Do not use the product in a tightly closed space for a long time.**  
Oxygen deficiency could occur.
- **When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.**  
Do not use the telephone or turn switches on or off.  
There is risk of explosion or fire.
- **If strange sounds, or small or smoke comes from product. Turn the breaker off or disconnect the power supply cable.**  
There is risk of electric shock or fire.
- **Stop operation and close the window in storm or hurricane. If possible, remove the product from the window before the hurricane arrives.**  
There is risk of property damage, failure of product, or electric shock.
- **Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)**  
There is risk of physical injury, electric shock, or product failure.
- **When the product is soaked (flooded or submerged), contact an Authorized service center.**  
There is risk of fire or electric shock.
- **Be caution that water could not enter the product.**  
There is risk of fire, electric shock, or product damage.
- **Ventilate the product from time to time when operating it together with a stove, etc.**  
There is risk of fire or electric shock.
- **Turn the main power off when cleaning or maintaining the product.**

There is risk of electric shock.

- **When the product is not be used for a long time, disconnect the power supply plug or turn off the breaker.**

There is risk of product damage or failure, or unintended operation.

- **Take care to ensure that nobody could step on or fall onto the outdoor unit.**

This could result in personal injury and product damage.

### ➤ CAUTION

- **Always check for gas (refrigerant) leakage after installation or repair of product.**

Low refrigerant levels may cause failure of product.

- **Install the drain hose to ensure that water is drained away properly.**

A bad connection may cause water leakage.

- **Keep level even when installing the product.**

To avoid vibration of water leakage.

- **Do not install the product where the noise or hot air from the outdoor unit could damage the neighborhoods.**

It may cause a problem for your neighbors.

- **Use two or more people to lift and transport the product.**

Avoid personal injury.

- **Do not install the product where it will be exposed to sea wind (salt spray) directly.**

It may cause corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient operation.

### ➤ Operational

- **Do not expose the skin directly to cool air for long periods of time. (Do not sit in the draft).**

This could harm to your health.

- **Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a**

**consumer air conditioner, not a precision refrigerant system.**

There is risk of damage or loss of property.

- **Do not block the inlet or outlet of air flow.**

It may cause product failure.

- **Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.**

There is risk of fire, electric shock, or damage to the plastic parts of the product.

- **Do not touch the metal parts of the product when removing the air filter. They are very sharp.**

There is risk of personal injury.

- **Do not step on or put anything on the product. (outdoor units)**

There is risk of personal injury and failure of product.

- **Always insert the filter securely. Clean the filter every two weeks or more often if necessary.**

A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.

- **Do not insert hands or other object through air inlet or outlet while the product is operated.**

There are sharp and moving parts that could cause personal injury.

- **Do not drink the water drained from the product.**

It is not sanitary could cause serious health issues.

- **Use a firm stool or ladder when cleaning or maintaining the product.**

Be careful and avoid personal injury.

- **Replace the all batteries in the remote control with new ones of the same type. Do not mix old and new batteries or different types of batteries.**

There is risk of fire or explosion.


- **Do not recharge or disassemble the batteries. Do not dispose of batteries in a fire.**


They may burn or explode.

- **If the liquid from the batteries gets onto your skin or clothes, wash it well with clean water. Do not use the remote of the batteries have leaked.**

The chemical in batteries could cause burns or other health hazards.

## 2. Function









### 3. Dimension

#### 3.1 Indoor unit (Alfa)

Dimension Mode	W	H	D
12K	815	280	215




#### 3.2 Outdoor unit (Alfa)




Dimension Mode	W	H	D
12K	760	590	285

### 3.3 Indoor unit (Corona)



Dimension Mode	W	H	D
18K	920	292	225


### 3.4 Outdoor unit (Corona)




Dimension Mode	W	H	D	L1	L2	L3
18K	845	695	335	560	360	560

### 3.5 Indoor unit(Inverter Eco)

Dimension Mode	W	H	D
7K	750	250	188
9K	750	250	188
12K	815	280	195




### 3.6 Outdoor unit(Inverter Eco)




Dimension Mode	W	H	D
7K	780	540	250
9K	780	540	250
12K	780	540	250

### 3.7 Indoor unit(Inverter Star)

Dimension Mode	W	H	D
7K	750	250	205
9K	750	250	205
12K	815	280	215



### 3.8 Outdoor unit(Inverter Star)



Dimension Mode	W	H	D
7K	760	590	285
9K	760	590	285
12K	760	590	285

## 4. Specification

Ac Alfa, Ac Corona

Model			MSH-18HRIN1	MSC-18HRIN1	MSE-09HRIN2	MSE-12HRIN2
Power supply			Ph-V-Hz 1, 220-240V~, 50Hz	1, 220-240V~, 50Hz	1, 220-240V~, 50Hz	1, 220-240V~, 50Hz
Cooling	Capacity	Btu/h	18000	18000	9000	12000
	Input	W	1670	1720	1100	1400
	Rated current	A	9.0	7.5	5.1	6.4
	EER	Btu/w.h	10.8	10.5	8.2	8.6
Heating	Capacity	Btu/h	20000	19000	12000	15000
	Input	W	1830	1790	1400	1700
	Rated current	A	9.9	7.7	6.3	7.5
	COP	W/W	3.2	3.11	8.6	8.8
Max. current			A 15.5	18	12	18
Starting current			A 9.0	9.0		
Compressor	Model		BA160X2CS-20KU	BA160X2CS-20KU	BG130X1C-20FZ	BG130X1C-20FZ
	Type		Rotary	Rotary	Rotary Inverter	Rotary Inverter
	Brand		TOSHIBA	TOSHIBA	TOSHIBA	TOSHIBA
	Capacity	Btu/h	16140	16140	9468	9468
	Input	W	1630	1630	890	890
	Rated current(RLA)	A	10.95	10.95	5.7	5.7
	Locked rotor Amp(LRA)	A	55	55		
	Thermal protector		CS-74	CS-74	CS-74	CS-74
	Capacitor	uF	No	No	No	No
	Refrigerant oil	ml	750	750	370	370
Indoor fan motor	Model		RPG28C	RPG28C	RPG13H	RPG13D
	Brand		Welling	Welling	Welling	Welling
	Input	W	45	55	39.5	44
	Capacitor	uF	1.5	1.5	1.2	1.5
	Speed(hi/mi/lo)	r/min	1200/1150/1000	1140/1060/980	1250/1100/850	1180/1000/850
Indoor air flow (Hi/Mi/Lo)			m3/h 800/700/600	800/700/600	520/460/410	580/500/420
Indoor noise level (Hi/Mi/Lo)			dB(A) 44/40/37	44/40/37	40/38/35	40/38/35
Outdoor fan motor	Model		YDK53-6K	YDK53-6C	YDK24-6F	YDK25-6-3
	Brand		Welling	Welling	Welling	Welling
	Input	W	130	125	56	75
	Capacitor	uF	3.0	3.0	2.5	2.0
	Speed	r/min	750	800	800	900
Outdoor air flow			m3/h 2500	2500	1600	1700
Outdoor noise level			dB(A) 58	58	58	58
Refrigerant type R410A			g 1650	1770	840	1200
Refrigerant piping	Liquid side/ Gas side	mm	Φ6.35/Φ12.7	Φ6.35/Φ12.7	Φ6.35/Φ9.53	Φ6.35/Φ12.7
	Max. pipe length	m	10	15	10	10
	Max. in level	m	5	8	5	5
Operation temp			°C 17-30	17-30	17-30	17-30
Ambient temp			°C -15-43	-15-43	-15-50	-15-50
Application area			m2 28-45	28-45		

Note:

The noise data is base on hemi-anechoic chamber, during actual operation; these values are normally somewhat different as a result of ambient condition.

The above design and specifications are subject to change without prior notice for product improvement.

## Inverter Eco

Model			MSG-07HRIN2	MSG-09HRIN2	MSG-12HRIN2
Power supply		Ph-V-Hz	1, 220-240V~, 50Hz	1, 220-240V~, 50Hz	1, 220-240V~, 50Hz
Cooling	Capacity	Btu/h	7000	9000	12000
	Input	W	780	990	1340
	Rated current	A	4.8	4.5	5.8
	EER	Btu/w.h	9.0	9.0	9.0
Heating	Capacity	Btu/h	9000	12000	15000
	Input	W	940	1240	1560
	Rated current	A	4.4	5.5	6.8
Compressor	Model		BG130X1C-20FZ	BG130X1C-20FZ	BG130X1C-20FZ
	Type		Rotary Inverter	Rotary Inverter	Rotary Inverter
	Brand		TOSHIBA	TOSHIBA	TOSHIBA
	Refrigeran Type		POE	POE	POE
	Capacitor	uF	No	No	No
	Refrigerant oil	ml	370	370	370
Indoor fan motor	Model		RPG13H	RPG13H	RPG13C
	Brand		Welling	Welling	Welling
	Capacitor	uF	1.2	1.2	1.5
	Speed(hi/mi/lo)	r/min	1050/950/750	1100/1000/800	1060/900/800
Indoor air flow (Hi/Mi/Lo)		m3/h	500/410/320	520/430/330	560/460/380
Indoor noise level (Hi/Mi/Lo)		dB(A)	35/32/26	36/32/26	36/32/26
Outdoor fan motor	Model		YDK23-6-3	YDK23-6-3	YDK23-6-3
	Brand		Welling	Welling	Welling
	Capacitor	uF	2.5	2.5	2.5
Outdoor noise level		dB(A)	51	51	53
Refrigerant type R407C		g	800	800	1150
Refrigerant piping	Liquid side/ Gas side	mm	Φ6.35/Φ9.53	Φ6.35/Φ9.53	Φ6.35/Φ12.7
	Max. pipe length	m	10	10	10
	Max. in level	m	5	5	5
Operation temp		°C	17-30	17-30	17-30
Ambient temp		°C	-15-45	-15-45	-15-43
Application area		m2	14-18	18-24	20-30

## Note:

The noise data is based on hemi-anechoic chamber, during actual operation; these values are normally somewhat different as a result of ambient condition.

The above design and specifications are subject to change without prior notice for product improvement.

## Inverter star


Model			MSG-09HRI	MSG-12HRI	MSG-21HRI	MSG-24HRI
Power supply		Ph-V-Hz	1, 220-240V~, 50Hz	1, 220-240V~, 50Hz	1, 220-240V~, 50Hz	1, 220-240V~, 50Hz
Cooling	Capacity	Btu/h	9000	12000	21000	24000
	Input	W	1080	1380	2450	2700
	Rated current	A	6.0	7.4	12.0	13.2
	EER	Btu/w.h	8.3	8.7	8.6	8.9
Heating	Capacity	Btu/h	12000	15000	28000	30000
	Input	W	1350	17900	2800	3030
	Rated current	A	7.2	10.5	14.0	15.1
	COP	W/W	2.6	2.5	2.9	2.9
Compressor	Model		2PV132N7BC02	2PV132N7BC02	BH240X2CS-20KU	BH240X2CS-20KU
	Type		Rotary	Rotary	Rotary	Rotary
	Brand		GD Matsushita	GD Matsushita	MIDEA TOSHIBA	MIDEA TOSHIBA
	Capacity	Btu/h	9500	9500		
	Input	W	855	855		
	Rated current(RLA)	A	5.1	5.1		
	Thermal protector		CS-7LN120	CS-7LN120		
	Capacitor	uF	No	No	No	No
	Refrigerant oil	ml	450	450	750	750
Indoor fan motor	Model		RPG13H	RPG20A	YDK36-4G	YDK36-4G
	Brand		Welling	Welling	Welling	Welling
	Input	W	36.5	35	70	70
	Capacitor	uF	1.2	1.0	3.0	3.0
	Speed(hi/mi/lo)	r/min	1100/1020/950	1060/900/800	1150/1050/950	1150/1050/950
Indoor air flow (Hi/Mi/Lo)		m3/h	500/430/330	540/460/380	1150/1050/950	1150/1050/950
Indoor noise level (Hi/Mi/Lo)		dB(A)	36/32/26	38/34/28	45/42/39	45/42/39
Outdoor fan motor	Model		YDK20-6G	YDK25-6-3	YDK53-6K	YDK53-6K
	Brand		Welling	Welling	Welling	Welling
	Input	W	70	75		
	Capacitor	uF	2.5	2	2.5	2.5
	Speed	r/min	800	890		
Outdoor noise level		dB(A)	50	53	55	55
Refrigerant type R22A		g	870	1120	1820	1820
Refrigerant piping	Liquid side/ Gas side	mm	Φ6.35/Φ9.53	Φ 6.35/Φ12.7	Φ6.35/Φ16	Φ6.35/Φ16
	Max. pipe length	m	10	10	20	20
	Max. in level	m	5	5	10	10
Operation temp		℃	17-30	17-30	17-30	17-30
Ambient temp		℃	-15-45	-15-45	-15-43	-15-43
Application area		m2	18-24	20-30	35-50	40-56

## Note:

The noise data is base on hemi-anechoic chamber, during actual operation; these values are normally somewhat different as a result of ambient condition.

The above design and specifications are subject to change without prior notice for product improvement.

## 5. Refrigerant cycle diagram






## 6. Operation limits

### 6.1 Cooling operation

Outdoor unit air temp. °C DB




Indoor air temp. °C DB

Note: The chart is the result from the continuous operation under constant air temperature conditions. However, excludes the initial pull-down stage.

### 6.2 Heating operation

Indoor air temp. °C DB




Outdoor unit air temp. °C DB

Note: The chart is the result from the continuous operation under constant air temperature conditions. However, excludes the initial pull-down stage.


## 7. Schematic diagram and Wiring diagram

### 7.1. Schematic diagram


#### 7.1.1 Display board(MSH-18HRIN1, MSC-18HRIN1)




#### 7.1.2 Indoor main PCB(MSH-18HRIN1, MSC-18HRIN1)




## 7.1.3 Outdoor main PCB(MSH-18HRIN1, MSC-18HRIN1)




## 7.1.4 Outdoor power PCB(MSH-18HRIN1, MSC-18HRIN1)



## 7.1..5 Indoor main PCB(Inverter Eco)





## 7.1.6 Outdoor main PCB(Inverter Eco)





## 7.2. Wiring diagram



### 7.2.1 MSH-18HRDN1



## 7.2.2 MSC-18HRIN1




## 7.2.3 MSE-09HRIN2, MSE-12HRIN2






## 7.2.4 MSG-07HRIN2, MSG-09HRIN2, MSG-12HRIN2


## 1 Indoor unit 7/9K



## 2 Indoor unit 12K



## 3. Outdoor unit



## 8. Installation details

### 8.1 Wrench torque sheet for installation

Outside diameter		Torque
mm	inch	Kg.m
φ 6.35	1/4	1.8
φ 9.52	3/8	4.2
φ 12.7	1/2	5.5
φ 15.88	5/8	6.6
φ 19.05	3/4	6.6



### 8.2 Connecting the cables

The power cord of connect should be selected according to the following specifications sheet.

	Grade				
Unit	7K	9K	12K	16K	18K
mm <sup>2</sup>	1.0	1.0	1.5	2.5	2.5

### 8.3 Pipe length and the elevation

Capacity Btu/h	Pipe size		Standard length (m)	Max. Elevation B (m)	Max. Elevation B (m)	Additional refrigerant (g/m)
	GAS	LIQUID				
7k~12K	3/8" (φ 9.52)	1/4" (φ 6.35)	5	5	10	30
	1/2" (φ 12.7)	1/4" (φ 6.35)	5	5	10	30
18K~28K	1/2" (φ 12.7)	1/4" (φ 6.35)	5	8	15	30
	5/8" (φ 15.88)	1/4" (φ 6.35)	5	10	20	30
	5/8" (φ 15.88)	3/8" (φ 9.52)	5	10	20	65



Caution:

Capacity is base on standard length and maximum allowance length is base of reliability.

Oil trap should be install per 5-7 meters.

## 8.4 Air purging of the piping and indoor unit


Required tools:

Hexagonal wrench; adjustable wrench; torque wrenches, wrench to hold the joints and gas leak detector.

Note:

The air in the indoor unit and in the piping must be purged. If air remains in the refrigeration piping, it will affect the compressor, reduce the cooling capacity, and could lead to a malfunction of unit.

Be sure, using a torque wrench to tighten the service port cap (after using the service port), so that it prevents the gas leakage from the refrigeration cycle.



### Procedure

1. **Recheck the piping connections.**
2. **Open the valve stem of the 2-way valve counterclockwise approximately 90°, wait 10 seconds, and then set it to closed position.**
  - Be sure to use a hexagonal wrench to operate the valve stem
3. **Check for gas leakage.**
  - Check the flare connection for gas leakage
4. **Purge the air from the system.**
  - Set the 2-way valve to the open position and remove the cap from the 3-way valve's service port.
  - Using the hexagonal wrench to press the valve core pin, discharge for three seconds and then wait for one minute.
5. **Use torque wrench to tighten the service port cap to a torque of 1.8 kg.m. (18n.m)**

6. **Set the 3-way valve to the opened position.**

7. **Mounted the valve stem nuts to the 2-way and 3-way valves.**

8. **Check for gas leakage.**


- At this time, especially check for gas leakage from the 2-way and 3-way stem nuts, and from the service port.

### Caution:

If gas leakage is discovered in step (3) above, take the following measures.

If the leaks stop when the piping connections are tightened further, continue working from step (4). If the gas leaks do not stop when the connections are retightened, repair the location of the leak, discharge all of the gas through the service port, and then recharge with the specified amount of gas from a gas cylinder.


## 8.5 Pumping down (Re-installation)



### Procedure

- 1. Confirm that both the 2-way and 3-way valves are set to the opened position.**
  - Remove the valve stem caps and confirm that the valve stems are in the opened position.
  - Be sure to use a hexagonal wrench to operate the valve stems.
- 2. Operate the unit for 10 to 15 minutes.**
- 3. Stop operation and wait for 3 minutes, then connect the charge set to the service port of the 3-way valve.**
  - Connect the charge hose with the push pin to the gas service port.
- 4. Air purging of the charge hose.**
  - Open the low-pressure valve on the charge set slightly to purge air from the charge hose.
- 5. Set the 2-way valve to the close position.**
- 6. Operate the air conditioner at the cooling cycle and stop it when the gauge indicates 0.1MPa.**
- 7. Immediately set the 3-way valve to the closed position.**
  - Do this quickly so that the gauge ends up indicating 0.3 to 0.5Mpa.
- 8. Disconnect the charge set, and amount the 2-way and 3-way valve's stem nuts and service port caps.**
  - Use a torque wrench to tighten the service port cap to a torque of 1.8 kg.m.
  - Be sure to check for gas leakage.


## 8.6 Re-air purging (Re-installation)



Procedure:

- 1. Confirm that both the 2-way and 3-way valves are set to the closed position.**
- 2. Connect the charge set and a charging cylinder to the service port of the 3-way valve.**
  - Leave the valve on the charging cylinder closed.
- 3. Air purging.**
  - Open the valves on the charging cylinder and the charge set. Purge the air by loosening the flare nut on the 2-way valve approximately 45° for 3 seconds then closing it for 1 minutes; repeat 3 times.
  - After purging the air, use a torque wrench to tighten the flare nut to on the 2-way valve.
- 4. Check the gas leakage.**
  - Check the flare connections for gas leakage.
- 5. Discharge the refrigerant.**
  - Close the valve on the charging cylinder and discharge the refrigerant until the gauge indicate 0.3 to 0.5 Mpa.
- 6. Disconnect the charge set and the charging cylinder, and set the 2-way and 3-way valves to the open position.**
  - Be sure to use a hexagonal wrench to operate the valve stems.
- 7. Mount the valve stems nuts and the service port cap.**
  - Be sure to use a torque wrench to tighten the service port cap to a torque 18N.m.
  - Be sure to check the gas leakage.


## 8.7 Balance refrigerant of the 2-way, 3-way valves



Procedure:

- 1. Confirm that both the 2-way and 3-way valves are set to the open position.**
- 2. Connect the charge set to the 3-way valve's service port.**
  - Leave the valve on the charge set closed.
  - Connect the charge hose with the push pin to the service port.
- 3. Open the valves (Low side) on the charge set and discharge the refrigerant until the gauge indicates 0.05 to 0.1 Mpa.**
  - If there is no air in the refrigeration cycle [the pressure when the air conditioner is not running is higher than 0.1Mpa, discharge the refrigerant until the gauge indicates 0.05 to 0.1 Mpa. If this is the case, it will not be necessary to apply a evacuation.
  - Discharge the refrigeration gradually; if it is discharged too suddenly, the refrigeration oil will be discharged.

## 8.8 Evacuation




Procedure:

- 1. Connect the vacuum pump to the charge set's centre hose.**
- 2. Evacuation for approximately one hour.**
  - Confirm that the gauge needle has moved toward -0.1 Mpa (-76 cmHg) [vacuum of 4 mmHg or less].
- 3. Close the valve (Low side) on the charge set, turn off the vacuum pump, and confirm that the gauge needle does not move (approximately 5 minutes after turning off the vacuum pump).**
- 4. Disconnect the charge hose from the vacuum pump.**
  - Vacuum pump oil, if the vacuum pump oil becomes dirty or depleted, replenish as needed.



## 8.9 Gas charging



Procedure:

**1. Connect the charge hose to the charging cylinder.**

- Connect the charge hose which you disconnected from the vacuum pump to the valve at the bottom of the cylinder.

**2. Purge the air from the charge hose.**

- Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).

**3. Open the valves (Low side) on the charge set and charge the system with liquid refrigerant.**

- If the system cannot be charge with the specified amount of refrigerant, it can be charged with a little at a time (approximately 150g each time) while operating the air conditioner in the cooling cycle; however, one time is not sufficient, wait approximately 1 minute and then repeat the procedure.(pumping down-pin).

**4. Immediately disconnect the charge hose from the 3-way valve's service port.**

- Stopping partway will allow the refrigerant to be discharged.
- If the system has been charged with liquid refrigerant while operating the air conditioner, turn off the air conditioner before disconnecting the hose.

**5. Mounted the valve stem caps and the service port**

- Use torque wrench to tighten the service port cap to a torque of 18N.m.
- Be sure to check for gas leakage.

## 9. Pressure table

Note:

The pressure data is from 3 way valve, the pressure data are pressure above atmosphere.

D: Dry bulb temp.

W: Wet bulb temp.

### 9.1 MSH-18HRIN1

Cooling mode		Outdoor temperature (Dry bulb temp)					
Indoor Conditions	Pressure	25°C	30°C	35°C	40°C	45°C	50°C
21°C D15°C W	Pressure( kg/cm <sup>2</sup> )	6.6	6.8	7.0	7.3	7.6	8.0
24°C D17°C W	Pressure( kg/cm <sup>2</sup> )	6.8	7.0	7.1	7.7	8.3	8.7
27°C D19°C W	Pressure( kg/cm <sup>2</sup> )	7.1	7.2	7.3	7.8	8.6	9.3
32°C D23°C W	Pressure( kg/cm <sup>2</sup> )	7.1	7.4	7.6	8.4	9.4	9.8

Heating mode		Outdoor temperature (Dry bulb temp)					
Indoor Conditions	Pressure	12°C D 11°C W	7°C D 6°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -9°C W	-15°C D -x°C W
15°C	Pressure( kg/cm <sup>2</sup> )	32.5	34.5	34.0	31.0	28.5	27.5
18°C	Pressure( kg/cm <sup>2</sup> )	35.0	34.5	35.5	32.5	29.5	28.0
20°C	Pressure( kg/cm <sup>2</sup> )	36.5	35.5	36.0	33.5	30.0	28.5
22°C	Pressure( kg/cm <sup>2</sup> )	36.5	37.0	36.5	35.0	32.5	29.5

### 9.2 MSC-18HRIN1

Cooling mode		Outdoor temperature (Dry bulb temp)					
Indoor Conditions	Pressure	25°C	30°C	35°C	40°C	45°C	50°C
21°C D15°C W	Pressure( kg/cm <sup>2</sup> )	6.6	6.8	7.0	7.3	7.6	8.0
24°C D17°C W	Pressure( kg/cm <sup>2</sup> )	6.8	7.0	7.1	7.7	8.3	8.7
27°C D19°C W	Pressure( kg/cm <sup>2</sup> )	7.1	7.2	7.3	7.8	8.6	9.3
32°C D23°C W	Pressure( kg/cm <sup>2</sup> )	7.1	7.4	7.6	8.4	9.4	9.8

Heating mode		Outdoor temperature (Dry bulb temp)					
Indoor Conditions	Pressure	12°C D 11°C W	7°C D 6°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -9°C W	-15°C D -x°C W
15°C	Pressure( kg/cm <sup>2</sup> )	32.5	34.5	34.0	31.0	28.5	27.5
18°C	Pressure( kg/cm <sup>2</sup> )	35.0	34.5	35.5	32.5	29.5	28.0
20°C	Pressure( kg/cm <sup>2</sup> )	36.5	35.5	36.0	33.5	30.0	28.5
22°C	Pressure( kg/cm <sup>2</sup> )	36.5	37.0	36.5	35.0	32.5	29.5

## 10. Capacity table

### 10.1 MSH-18HRIN1

COOLING		OUTDOOR TEMPERATURE DRY						
Indoor Conditions		21°C	25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity kW	3.513	3.903	4.550	4.849	4.177	3.251	2.333
	Sensitive capacity kW	2.635	2.927	3.413	3.738	3.133	2.438	1.749
	Input kW.	0.696	1.050	1.607	2.163	1.976	1.810	1.654
24°C D 17°C W	Total capacity kW	4.071	4.30	4.938	5.268	4.08	3.625	2.667
	Sensitive capacity kW	3.052	3.322	3.703	4.051	3.381	2.719	2.000
	Input kW.	0.731	1.183	1.621	2.106	2.012	1.851	1.680
27°C D 19°C W	Total capacity kW	4.362	4.921	5.205	5.287	5.024	4.213	3.271
	Sensitive capacity kW	3.287	3.690	3.958	4.110	3.768	3.160	2.461
	Input kW.	0.721	1.196	1.647	1.700	2.077	1.902	1.700
32°C D 23°C W	Total capacity kW	4.931	5.409	6.092	6.319	5.613	4.782	3.500
	Sensitive capacity kW	3.698	4.056	4.569	4.839	4.207	3.586	2.625
	Input kW.	0.704	1.206	1.755	2.213	2.118	1.962	1.720

HEATING			OUTDOOR CONDITIONS						
Indoor Conditions		24°C D 18°C W	12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-5°C D -6°C W	-7°C D -8°C W	-15°C D -16°C W
15°C	Capacity kW	7.355	7.108	6.663	6.208	5.265	4.621	4.428	3.482
	Input kW.	1.691	1.883	1.850	2.271	2.406	2.283	2.135	2.026
18°C	Capacity kW	7.310	7.021	6.582	6.133	5.255	4.689	4.507	3.638
	Input kW.	1.780	1.947	1.875	2.571	2.730	2.81	2.378	2.180
20°C	Capacity kW	7.280	6.897	5.987	5.802	5.394	4.740	4.563	3.744
	Input kW.	1.860	2.073	1.898	2.650	3.082	2.810	2.550	2.313
22°C	Capacity kW	7.241	6.821	5.947	5.750	5.400	4.768	4.592	3.738
	Input kW.	1.993	2.231	2.173	2.700	2.980	2.693	2.487	2.308
27°C	Capacity kW	7.103	6.667	5.969	5.883	5.418	4.807	4.671	3.714
	Input kW.	2.106	2.312	2.422	2.691	2.892	2.611	2.458	2.306

**10.2 MSC-18HRIN1**

COOLING		OUTDOOR TEMPERATURE DRY						
Indoor Conditions		21°C	25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity kW	3.513	3.903	4.550	4.849	4.177	3.251	2.333
	Sensitive capacity kW	2.635	2.927	3.413	3.738	3.133	2.438	1.749
	Input kW.	0.696	1.050	1.607	2.163	1.976	1.810	1.654
24°C D 17°C W	Total capacity kW	4.071	4.30	4.938	5.268	4.08	3.625	2.667
	Sensitive capacity kW	3.052	3.322	3.703	4.051	3.381	2.719	2.000
	Input kW.	0.731	1.183	1.621	2.106	2.012	1.851	1.680
27°C D 19°C W	Total capacity kW	4.362	4.921	5.205	5.287	5.024	4.213	3.271
	Sensitive capacity kW	3.287	3.690	3.958	4.110	3.768	3.160	2.461
	Input kW.	0.721	1.196	1.647	1.700	2.077	1.902	1.700
32°C D 23°C W	Total capacity kW	4.931	5.409	6.092	6.319	5.613	4.782	3.500
	Sensitive capacity kW	3.698	4.056	4.569	4.839	4.207	3.586	2.625
	Input kW.	0.704	1.206	1.755	2.213	2.118	1.962	1.720

HEATING			OUTDOOR CONDITIONS						
Indoor Conditions		24°C D 18°C W	12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-5°C D -6°C W	-7°C D -8°C W	-15°C D -16°C W
15°C	Capacity kW	7.355	7.108	6.663	6.208	5.265	4.621	4.428	3.482
	Input kW.	1.691	1.883	1.850	2.271	2.406	2.283	2.135	2.026
18°C	Capacity kW	7.310	7.021	6.582	6.133	5.255	4.689	4.507	3.638
	Input kW.	1.780	1.947	1.875	2.571	2.730	2.81	2.378	2.180
20°C	Capacity kW	7.280	6.897	5.987	5.802	5.394	4.740	4.563	3.744
	Input kW.	1.860	2.073	1.898	2.650	3.082	2.810	2.550	2.313
22°C	Capacity kW	7.241	6.821	5.947	5.750	5.400	4.768	4.592	3.738
	Input kW.	1.993	2.231	2.173	2.700	2.980	2.693	2.487	2.308
27°C	Capacity kW	7.103	6.667	5.969	5.883	5.418	4.807	4.671	3.714
	Input kW.	2.106	2.312	2.422	2.691	2.892	2.611	2.458	2.306

### 10.3 MSG-09HRI

SUMMER	Cooling mode	OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity kW	2.50	2.35	2.17	2.00	1.87	1.73
	Sensitive capacity kW	1.82	1.75	1.64	1.52	1.43	1.34
	Input kW.	0.86	0.90	0.94	1.02	1.13	1.17
24°C D 17°C W	Total capacity kW	2.71	2.58	2.42	2.28	2.13	1.96
	Sensitive capacity kW	1.99	1.93	1.84	1.75	1.64	1.52
	Input kW.	0.88	0.93	0.97	1.05	1.16	1.20
27°C D 19°C W	Total capacity kW	2.88	2.75	<b>2.60</b>	2.46	2.29	2.11
	Sensitive capacity kW	2.19	2.12	<b>2.03</b>	1.93	1.80	1.67
	Input kW.	0.91	0.96	<b>1.00</b>	1.08	1.20	1.24
32°C D 23°C W	Total capacity kW	3.21	3.08	2.98	2.77	2.53	2.38
	Sensitive capacity kW	2.47	2.40	2.34	2.19	2.02	1.93
	Input kW.	0.95	1.00	1.04	1.12	1.25	1.29
WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity kW	3.46	3.03	2.78	2.44	2.10	1.84
	Input kW.	1.05	0.96	0.89	0.82	0.72	0.65
18°C	Capacity kW	3.39	2.98	2.71	2.35	1.99	1.73
	Input kW.	1.08	0.97	0.90	0.84	0.74	0.66
20°C	Capacity kW	3.36	<b>2.93</b>	2.68	2.29	1.89	1.56
	Input kW.	1.11	<b>0.98</b>	0.93	0.86	0.76	0.70
22°C	Capacity kW	3.33	2.90	2.64	2.26	1.85	1.54
	Input kW.	1.15	0.99	0.95	0.90	0.81	0.72

### 10.4 MSG-12HRI

SUMMER	Cooling mode	OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity kW	3.36	3.16	2.93	2.69	2.52	2.33
	Sensitive capacity kW	2.46	2.36	2.21	2.05	1.92	1.80
	Input kW.	1.05	1.11	1.16	1.25	1.39	1.43
24°C D 17°C W	Total capacity kW	3.64	3.48	3.25	3.07	2.86	2.64
	Sensitive capacity kW	2.68	2.59	2.47	2.35	2.21	2.05
	Input kW.	1.09	1.15	1.19	1.29	1.43	1.48
27°C D 19°C W	Total capacity kW	3.88	3.71	<b>3.50</b>	3.31	3.08	2.84
	Sensitive capacity kW	2.95	2.85	<b>2.73</b>	2.60	2.43	2.25
	Input kW.	1.12	1.18	<b>1.23</b>	1.33	1.48	1.53
32°C D 23°C W	Total capacity kW	4.32	4.14	4.01	3.73	3.41	3.21
	Sensitive capacity kW	3.33	3.23	3.15	2.94	2.73	2.60
	Input kW.	1.16	1.23	1.28	1.38	1.54	1.59
WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity kW	4.50	3.94	3.61	3.17	2.73	2.40
	Input kW.	1.38	1.26	1.17	1.08	0.94	0.86
18°C	Capacity kW	4.41	3.87	3.52	3.06	2.59	2.25
	Input kW.	1.42	1.28	1.19	1.11	0.97	0.87
20°C	Capacity kW	4.37	<b>3.81</b>	3.48	2.98	2.45	2.03
	Input kW.	1.46	<b>1.29</b>	1.23	1.14	1.00	0.92
22°C	Capacity kW	4.33	3.77	3.43	2.94	2.41	2.00
	Input kW.	1.51	1.30	1.24	1.18	1.06	0.95

**10.5 MSG-21HRI**


SUMMER	Cooling mode	OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity kW	5.92	5.56	5.15	4.74	4.43	4.11
	Sensitive capacity kW	4.32	4.15	3.89	3.60	3.38	3.16
	Input kW.	1.97	2.08	2.16	2.33	2.59	2.68
24°C D 17°C W	Total capacity kW	6.41	6.12	5.72	5.41	5.04	4.65
	Sensitive capacity kW	4.71	4.56	4.35	4.14	3.88	3.60
	Input kW.	2.03	2.14	2.23	2.41	2.68	2.77
27°C D 19°C W	Total capacity kW	6.83	6.52	<b>6.16</b>	5.82	5.43	5.00
	Sensitive capacity kW	5.19	5.02	<b>4.80</b>	4.57	4.28	3.95
	Input kW.	2.09	2.21	<b>2.30</b>	2.48	2.76	2.85
32°C D 23°C W	Total capacity kW	7.60	7.29	7.05	6.56	6.00	5.65
	Sensitive capacity kW	5.85	5.69	5.54	5.18	4.80	4.58
	Input kW.	2.18	2.30	2.39	2.58	2.87	2.97
WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity kW	8.12	7.12	6.52	5.73	4.93	4.33
	Input kW.	2.58	2.34	2.18	2.01	1.76	1.59
18°C	Capacity kW	7.97	6.99	6.36	5.52	4.68	4.05
	Input kW.	2.64	2.38	2.21	2.07	1.81	1.62
20°C	Capacity kW	7.90	<b>6.88</b>	6.29	5.39	4.43	3.67
	Input kW.	2.72	<b>2.40</b>	2.28	2.11	1.86	1.70
22°C	Capacity kW	7.82	6.80	6.19	5.31	4.35	3.61
	Input kW.	2.81	2.42	2.31	2.19	1.98	1.77

**10.6 MSG-24HRI**

SUMMER	Cooling mode	OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity kW	6.76	6.35	5.88	5.41	5.05	4.69
	Sensitive capacity kW	4.93	4.74	4.44	4.11	3.86	3.61
	Input kW.	2.35	2.48	2.59	2.79	3.10	3.21
24°C D 17°C W	Total capacity kW	7.31	6.99	6.53	6.17	5.75	5.30
	Sensitive capacity kW	5.38	5.21	4.96	4.72	4.43	4.11
	Input kW.	2.43	2.56	2.67	2.88	3.20	3.31
27°C D 19°C W	Total capacity kW	7.79	7.44	<b>7.03</b>	6.64	6.19	5.71
	Sensitive capacity kW	5.92	5.73	<b>5.48</b>	5.22	4.88	4.51
	Input kW.	2.50	2.64	<b>2.75</b>	2.97	3.30	3.41
32°C D 23°C W	Total capacity kW	8.68	8.32	8.05	7.49	6.84	6.45
	Sensitive capacity kW	6.68	6.49	6.32	5.91	5.47	5.22
	Input kW.	2.60	2.75	2.86	3.09	3.43	3.55
WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity kW	9.33	8.19	7.50	6.58	5.67	4.98
	Input kW.	2.95	2.68	2.50	2.31	2.01	1.83
18°C	Capacity kW	9.16	8.04	7.31	6.35	5.38	4.66
	Input kW.	3.03	2.73	2.53	2.37	2.07	1.85
20°C	Capacity kW	9.08	<b>7.91</b>	7.23	6.19	5.09	4.22
	Input kW.	3.11	<b>2.75</b>	2.61	2.42	2.13	1.95
22°C	Capacity kW	9.00	7.82	7.12	6.10	5.01	4.15
	Input kW.	3.22	2.78	2.65	2.51	2.27	2.03

## 11. Electronic function

### 11.1. Display board



#### 11.1.1. AUTO indicator

This indicator illuminates when the air conditioner is in AUTO operation.

#### 11.1.2. TIMER indicator

This indicator illuminates when TIMER is set ON/OFF.

#### 11.1.3. PRE.-DEF. Indicator (For Cooling & Heating models only)

This indicator illuminates when the air conditioner starts defrosting automatically or when the warm air control feature is activated in heating mode.

#### 11.1.4. TEMPERATURE indicator

Usually it displays the temperature settings. When change the setting temperature, this indicator begins to flash, and stops 20 seconds later.

It displays the room temperature when the air conditioner is in FAN only operation.

When the unit stops operation, it returns to original factory settings.

Displays the malfunction code or protection code.

#### 11.1.5. OPERATION indicator

This indicator flashes after power is on and illuminates when the unit is in operation.

#### 11.1.6. FREQUENCY indicator

This indicator appears only when the compressor is in operation and indicates the current operating frequency.

### 11.2. Protection

#### 11.2.1. 3 minutes delay at restart for compressor.

11.2.2. Temperature protection of compressor top, compressor stops when the temp. of top of compressor is more than 115°C, compressor runs when the temp. of top of compressor is less than 100°C.

11.2.3. Voltage protection, unit stop when the voltage is more than 260V and less than 175V.

11.2.4. Inverter module Protection, Inverter module Protection itself has a protection function against current, voltage and temperature.

11.2.5. Sensor protection at open circuit and breaking disconnection

11.2.6. Fan Speed is out of control. When Indoor Fan Speed is too high(higher than 2100RPM)or too low(lower than 300RPM), the unit stops and LED displays failure information and can't return to normal operation automatically.

11.2.7. Cross Zero signal error warning. If there is no Cross Zero signals in 4 minutes, the unit stops and LED displays failure information and can't return to normal operation automatically.

### 11.3. Fan-only mode

Fan speed is high/mid/low/ Auto

### 11.4. Cooling mode

11.4.1. The 4-way valve is closed at cooling mode.

11.4.2. The action of the compressor and the outdoor fan:

	Condition T=Indoor Temp.	Compressor	Outdoor fan
Room temp. up	$T > T_s + 1$	On	On
	$T < T_s + 1$	Off	Off
Room temp. down	$T > T_s$	On	On
	$T < T_s$	Off	Off

## 11.4.3 Auto fan at cooling mode:

	Condition T=Indoor Temp.-Setting Temp.	Indoor fan speed
Room temp. up	$T < 1.5^{\circ}\text{C}$	Low
	$1.5^{\circ}\text{C} < T < 4^{\circ}\text{C}$	Mid.
	$T > 4^{\circ}\text{C}$	High
Room temp. down	$T > 3^{\circ}\text{C}$	High
	$1^{\circ}\text{C} < T < 3^{\circ}\text{C}$	Mid.
	$T < 1^{\circ}\text{C}$	Low

## 11.4.4 Anti-freezing control to indoor evaporator at cooling mode( T: evaporator temp. )

	Evaporator Temp.	Compressor
	$0^{\circ}\text{C} < T < 4^{\circ}\text{C}$	Decrease frequency of compressor
	$T < 0^{\circ}\text{C}$	Off

## 11.4.5 Current protection

	Model	Current	Compressor
Current up	MSH-18HRIN1	$I > 18\text{ A}$	Off
		$14.5\text{ A} < I < 18\text{ A}$	Decrease frequency of compressor
		$I < 12.0\text{ A}$	On
Current down	MSH-18HRIN1	$I > 17.5\text{ A}$	Off
		$14.0\text{ A} < I < 17.5\text{ A}$	Decrease frequency of compressor
		$I < 11.5\text{ A}$	On

## 11.4.6 Rated capacity test

Set mode to cooling mode

Set temp. to  $17^{\circ}\text{C}$

Set fan speed to high speed

Push turbo button 5 times in 10 seconds.

Using special remoter controller

After 5 hours, cancel rated capacity test

Turbo function

Increasing frequency of compressor

After operating 30 minutes, return automatically to the mode and temp. previously selected.

**11.5. Dehumidifying mode**

11.5.1 The 4-way valve is off

11.5.2 the indoor fan is fixed in breeze speed

11.5.3 Compressor run in low frequency

11.5.4 Low room temperature protection:

11.5.5 When room temperature decreases to below  $10^{\circ}\text{C}$ , compressor and outdoor fan will stop (indoor fan is Breeze). Dehumidifying operation will be resumed when room temperature restores to over  $12^{\circ}\text{C}$ .

11.5.6 At dehumidifying mode, the anti-freezing function of the indoor heat exchanger is the same as that of cooling mode.

**11.6. Heating mode**

11.6.1. Generally, the 4-way valve is open at heating mode, but it is closed at defrosting. 4-way valve must delay 2 minutes compared with compressor if the compressor changed into non-heating mode or turned off. 4-way valve doesn't delay in dehumidifying mode.

11.6.2. Generally, the outdoor fan is turned off with the on-off action of compressor in heating mode, except for the defrosting mode or the end of defrost.

11.6.3. Action of compressor and outdoor fan motor at heating mode: compressor must run for 7 minutes after starting and then judge temperature. Meanwhile other protections are still valid.



	Condition	Compressor	Outdoor fan
Room temp. up	$T > T_s + 3$	Off	Off
	$T < T_s + 3$	On	On
Room temp. down	$T < T_s + 2$	On	On
	$T > T_s + 2$	Off	Off

#### 11.6.4. Indoor Fan actions at heating mode

Indoor Fan can be set at HIGH/MID/LOW/AUTO by using a remote controller, but Anti-cold wind function prevails.

#### Anti-cold wind control function at heating mode

	Condition (T= Indoor exchanger temp.)	Indoor fan speed
Indoor exchanger temp. up	$T < 34^{\circ}\text{C}$	Off
	$34^{\circ}\text{C} < T < 37^{\circ}\text{C}$	Breeze
	$37^{\circ}\text{C} < T < 44^{\circ}\text{C}$	Low speed
	$T > 44^{\circ}\text{C}$	Setting fan speed
Indoor exchanger temp. down	$T > 38^{\circ}\text{C}$	Setting fan speed
	$33^{\circ}\text{C} < T < 38^{\circ}\text{C}$	Low speed
	$24^{\circ}\text{C} < T < 33^{\circ}\text{C}$	Breeze
	$T < 24^{\circ}\text{C}$	Off

When the indoor temp. gets to setting temp, indoor changes to breeze speed immediately, after 127 second, indoor fan stop.

#### 11.6.5. Auto wind at heating mode

	Condition (T=Indoor Temp.-Setting Temp.)	Indoor fan speed
Room temp. up	$T < 1.5^{\circ}\text{C}$	High
	$1.5^{\circ}\text{C} < T < 2.5^{\circ}\text{C}$	Med.
	$T > 2.5^{\circ}\text{C}$	Low
Room temp. down	$T < 1.0^{\circ}\text{C}$	High
	$1.0^{\circ}\text{C} < T < 2.0^{\circ}\text{C}$	Med.
	$T > 2.0^{\circ}\text{C}$	Low

#### 11.6.6. Indoor evaporator high-temperature protection at heating mode

Condition (T= Indoor exchanger temp.)	Compressor
$T < 48^{\circ}\text{C}$	On
$53^{\circ}\text{C} < T < 63^{\circ}\text{C}$	Decrease frequency of compressor
$T > 63^{\circ}\text{C}$	Off

#### 11.6.7. The current protection

	Model	Current	Compressor
Current up	18000btu/h	$I > 19.0\text{ A}$	Off
		$15.0\text{ A} < I < 19.0\text{ A}$	Decrease frequency of compressor
		$I < 12.5\text{ A}$	On
Current down	18000btu/h	$I > 18.5\text{ A}$	Off
		$14.5\text{ A} < I < 18.5\text{ A}$	Decrease frequency of compressor
		$I < 12.0\text{ A}$	On

#### 11.6.8. The temp. compensation

##### Jump setting in indoor PCB

J2	On	On	Off	Off
J3	On	Off	On	Off
$\Delta T$	$0^{\circ}\text{C}$	$-4^{\circ}\text{C}$	$-2^{\circ}\text{C}$	$0^{\circ}\text{C}$

## 11.7. Defrosting operation (Available for heating only).

### 11.7.1 Defrosting condition:

11.7.1.1. When outdoor temp. is more than 0°C,

Defrosting starts when meeting one of the following conditions,

- The temperature of outdoor heat exchanger remains consecutively lower than 3°C for more than 40 minutes, and the temperature remains consecutively -4°C for more than 3 minutes,
- The temperature of outdoor heat exchanger remains consecutively lower than 3°C for more than 80 minutes, and the temperature remains consecutively -2°C for more than 3 minutes

11.7.1.2. When outdoor temp. is less than 0°C,

Defrosting starts when meeting one of the following conditions,

- The temperature of outdoor heat exchanger remains consecutively lower than 3°C for more than 40 minutes, and the temperature remains consecutively -6°C for more than 3 minutes,
- The temperature of outdoor heat exchanger remains consecutively lower than 3°C for more than 40 minutes, and the temperature remains consecutively -6°C for more than 3 minutes,
- The temperature of indoor unit pipe decreases 5°C than before


11.7.1.3. The temperature of outdoor heat exchanger remains consecutively lower than 3°C for more than 120 minutes, and the temperature remains consecutively -2°C for more than 3 minutes

### 11.7.2 Ending condition of defrosting

If one of following conditions is satisfied, end the defrost and turn into heating mode:

- The defrost time has reached to 10 minutes.
- When the temperature of outdoor heat exchanger rises up to 8°C and this continues for more than 80 seconds.
- When the temperature of outdoor heat exchanger rises up to 12°C

### 11.7.3 Defrosting Actions:



### 11.7.4 Rated capacity test

- Set mode to cooling mode
- Set temp. to 30 °C
- Set fan speed to high speed
- Push turbo button 5 times in 10 seconds.
- Using special remoter controller
- After 5 hours, cancel rated capacity test

## 11.8. Outdoor low temperature protection (optional)

Factory standard unit has not this function.

Unit stops when outdoor temp. is low than -15°C and lasting time more than 60 minutes, and unit runs again when outdoor temp. more than -12°C.

When indoor PCB J1 jump is on, this function is available.

## 11.9. Automatic operation mode

The air conditioner automatically selects one of the following operation modes: cooling, heating or fan

only according to the temp. difference between room temp. (TA) and set temp. (TS).

TA—TS	Operation mode
TA—TS>2℃	Cooling
-1℃≤TA-TS≤+2℃	Fan-only
TA-TS<-1℃	Heating (air-only for cooling only type)

### 11.10. Manual switch

11.10.1 Mode changes when push this button .

Cooling mode→ Auto mode→Unit off→ Cooling mode

11.10.2 At Cooling mode, after 30 minutes cooling operation whose fan speed is set as low, the A/C operates with a setting temp. of 24℃.

11.10.3 At auto mode, the A/C operates with a set temp. of 24℃

### 11.11. Timer Function

11.11.1 The maximum length of timer is 24 hours and the minimum resolving power is 15 minutes.

11.11.2 Timer on: first turn off the A/C, the A/C will be automatically on at the set time.

11.11.3 Timer off: first turn on the A/C, the A/C will be automatically off at the set time

11.11.4 Timer on/off function( on time is earlier than off time): first turn off the A/C, it will be automatically on at set time, and later be off at the set time, then unit turns on at set time.

11.11.5 Timer off/on function( off time is earlier than on time): first turn on the A/C, it will be automatically off at set time, and later be on at the set time, then unit turns off at set time.

### 11.12. Sleep mode

11.12.1 It is available at cooling, heating or auto mode.

11.12.2 Cooling:

The set temperature rise 1℃ per hour. Two hours later, the set temperature will maintain as a constant and the fan speed is kept at low speed.

11.12.3 Heating:

The set temperature decrease 1℃ per hour. Two hours later, the set temperature will maintain as a constant and the air circulation is kept at low speed (Cold air proof function takes precedence over all).

11.12.4 Auto:

The Sleep Mode running function operates in accordance with selected running mode by auto mode.

11.12.5 After 7 hours, unit cancels this modes automatically.

### 11.13. Auto restart function

In case of a sudden power failure, this function automatically sets the unit to previous settings before the power failure when power returns.

### 11.14. Turbo function

The indoor fan will work in super high speed, the frequency of compressor will increase, the max run time is 30 minutes. After 30 minutes, the unit will work in previous setting.

### 11.15. Plasma

Plasma turns on when the indoor fan runs.

Plasma turns off automatically when front panel is opened.

Plasma is optional function.

## 12. Model and Parameters

Model	MSH-18HRDN1	MSC-18HRDN1
RACFAN	1180	1140
RAHFAN	1180	1140
RATIFC	59	59
RATIFH	57	57
SLEEPTMC	7	7
FANCSHIGH	1180	1180
FANHSHIGH	1180	1180
FANCHIGH	1180	1140
FANHHIGH	1180	1140
FANMID	1100	1060
FANLOW	980	980
FANSLOW	900	900
F1	42	42
F2	47	47
F3	52	52
F4	55	55
F5	58	58
F6	64	64
F7	70	70
F8	76	76
F9	82	82
F10	88	88
I1COOL	12	12
I2COOL	14.5	14.5
I3COOL	18	18
I1HEAT	12.5	12.5
I2HEAT	15	15
I3HEAT	19	19
TCDI	-6	-6
TCDE1	20	20
TCDE2	12	12
TEL2	26	24
TEH2	53	53
ANGLSTART	190	0
ANGLOFF	115	141
ANGLHEATMAX	13	11
ANGLHEAT	20	34
ANGLHEATMIN	48	51
ANGLSMALL	115	77
ANGLCOOLMAX	186	85
ANGLCOOL	175	68
ANGLCOOLMIN	160	56
PDELAYCOUNT	127	127
V1	F6	F6
V2	F3	F3

Model	MSE-09HRDN1	MSE-12HRDN1
flag0	00	00
MacType	05	05
RatiFC	66	82
RatiFH	76	92
SleepTim	7	7
FanCSHigh	1300	1250
FanHSHigh	1300	1250
FanCHigh	1250	1180
FanHHigh	1250	1180
FanMid	1100	1100
FanLow	880	850
FanSlow	800	750
F1	34	33
F2	38	47
F3	44	57
F4	59	62
F5	63	72
F6	66	82
F7	73	88
F8	76	92
F9	95	103
F10	105	107
I1Cool	7.0	8.5
I2Cool	8.0	10.0
I3Cool	10.5	12
I1Heat	8.5	10.5
I2Heat	10.0	12.0
I3Heat	12.0	13.5
TCDI	-9	-9
TCDE1	20	20
RACFAN	1250	1180
RAHFAN	1250	1180
TEL1	24	24
TEH2	53	53
ANGLSTART	200	193
ANGLOFF	110	101
ANGLHEATMAX	18	11
ANGLHEAT	27	17
ANGLHEATMIN	53	51
TEL2	33	33
ANGLCOOLMAX	186	180
ANGLCOOL	183	176
ANGLCOOLMIN	160	155
TCDE2	8	8
PDELAYCOUNT	127	127
TEL5	36	36
TEL6	40	40
PARASUM		

## 13. Troubleshooting


### 13.1 Indoor Unit Error Display

Display	LED STATUS
E0	EEPROM error
E1	Indoor / outdoor units communication protection
E2	Zero-crossing examination error
E3	Fan speed beyond control
E5	Open or short circuit of outdoor temperature sensor
E6	Room temperature or evaporator temperature sensor open or short circuit of
P0	Module protection
P1	Over voltage or too low voltage protection
P2	Compressor top protection against temperature
P3	Outdoor low temp. protection
P4	Inverter compressor drive error

**Note: E4: Reserved function**


#### 13.1.1

Display	LED STATUS
E0	EEPROM parameter error




#### 13.1.2 circuit or software error on indoor control board


Display	LED STATUS
E1	Indoor / outdoor units communication protection



Display	LED STATUS
E2	Zero-crossing examination error




Display	LED STATUS
E3	Fan speed beyond control




## 13.1.5

Display	LED STATUS
E5	Open or short circuit of outdoor temperature sensor



## 13.1.6


Display	LED STATUS
E6	Room temperature or evaporator temperature sensor open or short circuit



## 13.1.7


Display	LED STATUS
P0	Module protection





#### 13.1.8


Display	LED STATUS
P1	Over voltage or too low voltage protection



#### 13.1.9

Display	LED STATUS
P2	Compressor top protection against temperature

Off: 115 °C; On: 100 °C




## 13.1.10

Display	LED STATUS
P3	Outdoor low temp. protection


This is optional, factory standard unit has not this function.

Unit stops when outdoor temp. is low than -15°C and lasting time more than 60 minutes, and unit runs again when outdoor temp. more than -12°C.



### 13.2 Diagnostic chart


After energizing, no indicator is lighted and the air conditioner can't be operated.




### 13.3 Resetting phenomenon often occurs during operation

(That is automatically entering to the status when power is on.)


The reason is that the instantaneous voltage of main chip is less than 4.5V. Check according to the following procedure:




### 13.4 Operation lamp flashes and Timer lamp off



### 13.5 Operation lamp flashes and Timer lamp on



### 13.6 Operation lamp off and Timer lamp flashes



### 13.7 Operation lamp on and Timer lamp flashes

EEROM error, indoor PCB is defective.

### 13.8 Operation lamp flashes, Timer lamp flashes

This is alarm signal when the main chip can't detect over-zero signal. When such failure occurs, the main control board must have fault.

**14 Characteristic of temperature sensor**

Temp. °C	Resistance KΩ	Temp. °C	Resistance KΩ	Temp. °C	Resistance KΩ
-10	62.2756	17	14.6181	44	4.3874
-9	58.7079	18	13.918	45	4.2126
-8	56.3694	19	13.2631	46	4.0459
-7	52.2438	20	12.6431	47	3.8867
-6	49.3161	21	12.0561	48	3.7348
-5	46.5725	22	11.5	49	3.5896
-4	44	23	10.9731	50	3.451
-3	41.5878	24	10.4736	51	3.3185
-2	39.8239	25	10	52	3.1918
-1	37.1988	26	9.5507	53	3.0707
0	35.2024	27	9.1245	54	2.959
1	33.3269	28	8.7198	55	2.8442
2	31.5635	29	8.3357	56	2.7382
3	29.9058	30	7.9708	57	2.6368
4	28.3459	31	7.6241	58	2.5397
5	26.8778	32	7.2946	59	2.4468
6	25.4954	33	6.9814	60	2.3577
7	24.1932	34	6.6835	61	2.2725
8	22.5662	35	6.4002	62	2.1907
9	21.8094	36	6.1306	63	2.1124
10	20.7184	37	5.8736	64	2.0373
11	19.6891	38	5.6296	65	1.9653
12	18.7177	39	5.3969	66	1.8963
13	17.8005	40	5.1752	67	1.830
14	16.9341	41	4.9639	68	1.7665
15	16.1156	42	4.7625	69	1.7055
16	15.3418	43	4.5705	70	1.6469